


WinCounter Main Screen

Eight sensors showing today's raw traffic and a Differential Total "Total Traffic" which in this case is all 8 sensors totalled together and divided by 2.



This Differential Total is set up by going to Tools/Options/Totals and add new total.